

NAIC-ID(RS)T-0300-96

# NATIONAL AIR INTELLIGENCE CENTER



AUTOMATION OF TELEMETRY SUBSYSTEM MONITORING AND  
CONTROL IN SPACE FLIGHT TELEMETRY AND CONTROL SYSTEMS

by

Li Xiaodong

DATE OCT 1996 1000 2000 3000 4000 5000 6000 7000 8000 9000 10000 11000 12000 13000 14000 15000 16000 17000 18000 19000 20000 21000 22000 23000 24000 25000 26000 27000 28000 29000 30000 31000 32000 33000 34000 35000 36000 37000 38000 39000 40000 41000 42000 43000 44000 45000 46000 47000 48000 49000 50000 51000 52000 53000 54000 55000 56000 57000 58000 59000 60000 61000 62000 63000 64000 65000 66000 67000 68000 69000 70000 71000 72000 73000 74000 75000 76000 77000 78000 79000 80000 81000 82000 83000 84000 85000 86000 87000 88000 89000 90000 91000 92000 93000 94000 95000 96000 97000 98000 99000 100000 101000 102000 103000 104000 105000 106000 107000 108000 109000 110000 111000 112000 113000 114000 115000 116000 117000 118000 119000 120000 121000 122000 123000 124000 125000 126000 127000 128000 129000 130000 131000 132000 133000 134000 135000 136000 137000 138000 139000 140000 141000 142000 143000 144000 145000 146000 147000 148000 149000 150000 151000 152000 153000 154000 155000 156000 157000 158000 159000 160000 161000 162000 163000 164000 165000 166000 167000 168000 169000 170000 171000 172000 173000 174000 175000 176000 177000 178000 179000 180000 181000 182000 183000 184000 185000 186000 187000 188000 189000 190000 191000 192000 193000 194000 195000 196000 197000 198000 199000 200000 201000 202000 203000 204000 205000 206000 207000 208000 209000 210000 211000 212000 213000 214000 215000 216000 217000 218000 219000 220000 221000 222000 223000 224000 225000 226000 227000 228000 229000 230000 231000 232000 233000 234000 235000 236000 237000 238000 239000 240000 241000 242000 243000 244000 245000 246000 247000 248000 249000 250000 251000 252000 253000 254000 255000 256000 257000 258000 259000 260000 261000 262000 263000 264000 265000 266000 267000 268000 269000 270000 271000 272000 273000 274000 275000 276000 277000 278000 279000 280000 281000 282000 283000 284000 285000 286000 287000 288000 289000 290000 291000 292000 293000 294000 295000 296000 297000 298000 299000 300000 301000 302000 303000 304000 305000 306000 307000 308000 309000 310000 311000 312000 313000 314000 315000 316000 317000 318000 319000 320000 321000 322000 323000 324000 325000 326000 327000 328000 329000 330000 331000 332000 333000 334000 335000 336000 337000 338000 339000 340000 341000 342000 343000 344000 345000 346000 347000 348000 349000 350000 351000 352000 353000 354000 355000 356000 357000 358000 359000 360000 361000 362000 363000 364000 365000 366000 367000 368000 369000 370000 371000 372000 373000 374000 375000 376000 377000 378000 379000 380000 381000 382000 383000 384000 385000 386000 387000 388000 389000 390000 391000 392000 393000 394000 395000 396000 397000 398000 399000 400000 401000 402000 403000 404000 405000 406000 407000 408000 409000 410000 411000 412000 413000 414000 415000 416000 417000 418000 419000 420000 421000 422000 423000 424000 425000 426000 427000 428000 429000 430000 431000 432000 433000 434000 435000 436000 437000 438000 439000 440000 441000 442000 443000 444000 445000 446000 447000 448000 449000 450000 451000 452000 453000 454000 455000 456000 457000 458000 459000 460000 461000 462000 463000 464000 465000 466000 467000 468000 469000 470000 471000 472000 473000 474000 475000 476000 477000 478000 479000 480000 481000 482000 483000 484000 485000 486000 487000 488000 489000 490000 491000 492000 493000 494000 495000 496000 497000 498000 499000 500000 501000 502000 503000 504000 505000 506000 507000 508000 509000 510000 511000 512000 513000 514000 515000 516000 517000 518000 519000 520000 521000 522000 523000 524000 525000 526000 527000 528000 529000 530000 531000 532000 533000 534000 535000 536000 537000 538000 539000 540000 541000 542000 543000 544000 545000 546000 547000 548000 549000 550000 551000 552000 553000 554000 555000 556000 557000 558000 559000 560000 561000 562000 563000 564000 565000 566000 567000 568000 569000 570000 571000 572000 573000 574000 575000 576000 577000 578000 579000 580000 581000 582000 583000 584000 585000 586000 587000 588000 589000 589000 590000 591000 592000 593000 594000 595000 596000 597000 598000 599000 600000 601000 602000 603000 604000 605000 606000 607000 608000 609000 610000 611000 612000 613000 614000 615000 616000 617000 618000 619000 620000 621000 622000 623000 624000 625000 626000 627000 628000 629000 630000 631000 632000 633000 634000 635000 636000 637000 638000 639000 640000 641000 642000 643000 644000 645000 646000 647000 648000 649000 650000 651000 652000 653000 654000 655000 656000 657000 658000 659000 660000 661000 662000 663000 664000 665000 666000 667000 668000 669000 670000 671000 672000 673000 674000 675000 676000 677000 678000 679000 680000 681000 682000 683000 684000 685000 686000 687000 688000 689000 690000 691000 692000 693000 694000 695000 696000 697000 698000 699000 700000 701000 702000 703000 704000 705000 706000 707000 708000 709000 710000 711000 712000 713000 714000 715000 716000 717000 718000 719000 720000 721000 722000 723000 724000 725000 726000 727000 728000 729000 730000 731000 732000 733000 734000 735000 736000 737000 738000 739000 740000 741000 742000 743000 744000 745000 746000 747000 748000 749000 750000 751000 752000 753000 754000 755000 756000 757000 758000 759000 760000 761000 762000 763000 764000 765000 766000 767000 768000 769000 770000 771000 772000 773000 774000 775000 776000 777000 778000 779000 780000 781000 782000 783000 784000 785000 786000 787000 788000 789000 789000 790000 791000 792000 793000 794000 795000 796000 797000 798000 799000 800000 801000 802000 803000 804000 805000 806000 807000 808000 809000 810000 811000 812000 813000 814000 815000 816000 817000 818000 819000 820000 821000 822000 823000 824000 825000 826000 827000 828000 829000 830000 831000 832000 833000 834000 835000 836000 837000 838000 839000 840000 841000 842000 843000 844000 845000 846000 847000 848000 849000 850000 851000 852000 853000 854000 855000 856000 857000 858000 859000 860000 861000 862000 863000 864000 865000 866000 867000 868000 869000 869000 870000 871000 872000 873000 874000 875000 876000 877000 878000 879000 879000 880000 881000 882000 883000 884000 885000 886000 887000 888000 889000 889000 890000 891000 892000 893000 894000 895000 896000 897000 898000 899000 900000 901000 902000 903000 904000 905000 906000 907000 908000 909000 910000 911000 912000 913000 914000 915000 916000 917000 918000 919000 919000 920000 921000 922000 923000 924000 925000 926000 927000 928000 929000 929000 930000 931000 932000 933000 934000 935000 936000 937000 938000 939000 939000 940000 941000 942000 943000 944000 945000 946000 947000 948000 949000 949000 950000 951000 952000 953000 954000 955000 956000 957000 958000 959000 959000 960000 961000 962000 963000 964000 965000 966000 967000 968000 969000 969000 970000 971000 972000 973000 974000 975000 976000 977000 978000 979000 979000 980000 981000 982000 983000 984000 985000 986000 987000 988000 989000 989000 990000 991000 992000 993000 994000 995000 996000 997000 998000 999000 1000000 1001000 1002000 1003000 1004000 1005000 1006000 1007000 1008000 1009000 1009000 1010000 1011000 1012000 1013000 1014000 1015000 1016000 1017000 1018000 1019000 1019000 1020000 1021000 1022000 1023000 1024000 1025000 1026000 1027000 1028000 1029000 1029000 1030000 1031000 1032000 1033000 1034000 1035000 1036000 1037000 1038000 1039000 1039000 1040000 1041000 1042000 1043000 1044000 1045000 1046000 1047000 1048000 1049000 1049000 1050000 1051000 1052000 1053000 1054000 1055000 1056000 1057000 1058000 1059000 1059000 1060000 1061000 1062000 1063000 1064000 1065000 1066000 1067000 1068000 1069000 1069000 1070000 1071000 1072000 1073000 1074000 1075000 1076000 1077000 1078000 1079000 1079000 1080000 1081000 1082000 1083000 1084000 1085000 1086000 1087000 1088000 1089000 1089000 1090000 1091000 1092000 1093000 1094000 1095000 1096000 1097000 1098000 1099000 1099000 1100000 1101000 1102000 1103000 1104000 1105000 1106000 1107000 1108000 1109000 1109000 1110000 1111000 1112000 1113000 1114000 1115000 1116000 1117000 1118000 1119000 1119000 1120000 1121000 1122000 1123000 1124000 1125000 1126000 1127000 1128000 1129000 1129000 1130000 1131000 1132000 1133000 1134000 1135000 1136000 1137000 1138000 1139000 1139000 1140000 1141000 1142000 1143000 1144000 1145000 1146000 1147000 1148000 1149000 1149000 1150000 1151000 1152000 1153000 1154000 1155000 1156000 1157000 1158000 1159000 1159000 1160000 1161000 1162000 1163000 1164000 1165000 1166000 1167000 1168000 1169000 1169000 1170000 1171000 1172000 1173000 1174000 1175000 1176000 1177000 1178000 1179000 1179000 1180000 1181000 1182000 1183000 1184000 1185000 1186000 1187000 1188000 1189000 1189000 1190000 1191000 1192000 1193000 1194000 1195000 1196000 1197000 1198000 1198000 1199000 1199000 1200000 1201000 1202000 1203000 1204000 1205000 1206000 1207000 1208000 1209000 1209000 1210000 1211000 1212000 1213000 1214000 1215000 1216000 1217000 1218000 1219000 1219000 1220000 1221000 1222000 1223000 1224000 1225000 1226000 1227000 1228000 1229000 1229000 1230000 1231000 1232000 1233000 1234000 1235000 1236000 1237000 1238000 1239000 1239000 1240000 1241000 1242000 1243000 1244000 1245000 1246000 1247000 1248000 1249000 1249000 1250000 1251000 1252000 1253000 1254000 1255000 1256000 1257000 1258000 1259000 1259000 1260000 1261000 1262000 1263000 1264000 1265000 1266000 1267000 1268000 1269000 1269000 1270000 1271000 1272000 1273000 1274000 1275000 1276000 1277000 1278000 1279000 1279000 1280000 1281000 1282000 1283000 1284000 1285000 1286000 1287000 1288000 1289000 1289000 1290000 1291000 1292000 1293000 1294000 1295000 1296000 1297000 1298000 1298000 1299000 1299000 1300000 1301000 1302000 1303000 1304000 1305000 1306000 1307000 1308000 1309000 1309000 1310000 1311000 1312000 1313000 1314000 1315000 1316000 1317000 1318000 1319000 1319000 1320000 1321000 1322000 1323000 1324000 1325000 1326000 1327000 1328000 1329000 1329000 1330000 1331000 1332000 1333000 1334000 1335000 1336000 1337000 1338000 1339000 1339000 1340000 1341000 1342000 1343000 1344000 1345000 1346000 1347000 1348000 1349000 1349000 1350000 1351000 1352000 1353000 1354000 1355000 1356000 1357000 1358000 1359000 1359000 1360000 1361000 1362000 1363000 1364000 1365000 1366000 1367000 1368000 1369000 1369000 1370000 1371000 1372000 1373000 1374000 1375000 1376000 1377000 1378000 1379000 1379000 1380000 1381000 1382000 1383000 1384000 1385000 1386000 1387000 1388000 1389000 1389000 1390000 1391000 1392000 1393000 1394000 1395000 1396000 1397000 1398000 1398000 1399000 1399000 1400000 1401000 1402000 1403000 1404000 1405000 1406000 1407000 1408000 1409000 1409000 1410000 1411000 1412000 1413000 1414000 1415000 1416000 1417000 1418000 1419000 1419000 1420000 1421000 1422000 1423000 1424000 1425000 1426000 1427000 1428000 1429000 1429000 1430000 1431000 1432000 1433000 1434000 1435000 1436000 1437000 1438000 1439000 1439000 1440000 1441000 1442000 1443000 1444000 1445000 1446000 1447000 1448000 1449000 1449000 1450000 1451000 1452000 1453000 1454000 1455000 1456000 1457000 1458000 145

**HUMAN TRANSLATION**

NAIC-ID(RS)T-0300-96

16 December 1996

MICROFICHE NR:

AUTOMATION OF TELEMETRY SUBSYSTEM MONITORING AND  
CONTROL IN SPACE FLIGHT TELEMETRY AND CONTROL SYSTEMS

By: Li Xiaodong

English pages: 13

Source: Cama, China Astronautics and Missilery Abstracts,  
Vol. 3, Nr. 1, 1996; pp. 21-26

Country of origin: China

Translated by: SCITRAN

F33657-84-D-0165

Requester: NAIC/TASC/Lt Lori A. Thorson

Approved for public release: distribution unlimited.

THIS TRANSLATION IS A RENDITION OF THE ORIGINAL  
FOREIGN TEXT WITHOUT ANY ANALYTICAL OR EDITO-  
RIAL COMMENT STATEMENTS OR THEORIES ADVO-  
CATED OR IMPLIED ARE THOSE OF THE SOURCE AND  
DO NOT NECESSARILY REFLECT THE POSITION OR  
OPINION OF THE NATIONAL AIR INTELLIGENCE CENTER.

PREPARED BY:

TRANSLATION SERVICES  
NATIONAL AIR INTELLIGENCE CENTER  
WPAFB, OHIO

**GRAPHICS DISCLAIMER**

**All figures, graphics, tables, equations, etc. merged into this  
translation were extracted from the best quality copy available.**

AUTOMATION OF TELEMETRY SUBSYSTEM MONITORING AND CONTROL IN  
SPACE FLIGHT TELEMETRY AND CONTROL SYSTEMS

Li Xiaodong

Translation of "Hang Tian Ce Kong Xi Tong Zhong Yao Ce Fen Xi Tong  
Jian Kong Zi Dong Hua"; Telemetry and Remote Control, Vol.15,  
No.5, October 1994, pp 21-26

**ABSTRACT** This article introduces the realization of space flight telemetry and control system monitoring and control automation. Specific discussions are made of methods to realize automation of monitoring and control associated with monitoring and control processors for main system control units and telemetry subsystems as well as the interiors of telemetry subsystems. The realizing of control and monitoring automation simplifies telemetry and control station management and reduces telemetry and control system operating and maintenance personnel, providing advantages for telemetry and control system operation and maintenance.

**KEY WORDS** Monitoring and control automation technology  
Computer communications

## 1 INTRODUCTION

Following along with the breakneck development of computer technology with every passing day, space flight telemetry and control system performance not only depends on its communications channel indices, orbital measurement precision, signal acquisition time, telemetry error code rates, and so on. It also depends, moreover, on such utilization properties as practical utility as well as ease of maintenance, and so forth. Monitoring and control automation realizes centralized management for systems as a whole and unified control. Causing control, which was originally dispersed in each subsystem to be concentrated in main control units reduces total system control and maintenance personnel, improving the level of automation. Moreover, it is capable of discovering in a timely manner changes in the statuses of various subsystems, finding the sources of malfunctions in a timely way, and causing the elimination of malfunctions early on. The realization of monitoring and control automation very, very greatly improves telemetry and control system performance. Following along with the step by step development of China's space flight enterprises, in order to catch up to and surpass advanced levels associated with world space flight telemetry and control technologies, in 1990, the national defense science and industry committee put forward a tasking associated with the development of

a new generation C wave band standard model telemetry and control system. The tasking documents pointed out that the primary characteristic of a new generation of C wave band telemetry and control systems is nothing else than that the level of monitoring and control automation must achieve a new leap. Telemetry and control systems as a whole are composed of such various subsystems as main control units, angular measurements, range measurements, telemetry, remote control, centralizers, receivers, transmitters, and so on. Main control unit subsystems control the entire telemetry and control system operation. Control processes are realized through communication between main control units and monitoring and control processors associated with various subsystems. Through communication, the various subsystems take their own operational statuses, such technical indices as operational parameters, and so on and transmit them to central control units. Operating personnel are capable of directly comprehending, at the central control units, the operating statuses of the entire system. Various subsystems are also capable of receiving commands put out by central control units in order to alter their own operating status, operating parameters, and so on. In this way, telemetry and control stations only need one or two people and, at central control units, it is then possible to monitor and control the operation of the entire system--making it possible for the tasks that were originally able to be completed by several tens of personnel to then be capable of being finished by one or two people. The completion and delivery of this telemetry and control system improved the level of China's space flight telemetry and control system automation of monitoring and control.

## 2 OVERALL COMPOSITION

In situations where control devices have given rise to malfunctions--in order to make systems operate normally, guaranteeing system reliability as well as the realization of centralized control--telemetry and control systems realize three level monitoring and control. The line and block chart is shown in Fig.1.

Level 1 Control is carried out on the panels of various assembly casings.

Level 2 In various subsystem monitoring and control processors, control is carried out with regard to different combinations of the subsystems in question. That is, parameter settings and configuration inquiries are carried out on various assemblies. In conjunction with that, parameters and configurations are taken and sent to central control units.

Level 3 At main control unit locations, control is carried out with regard to entire telemetry and control systems. During control at this level, subsystem monitoring and control processors are located at very important positions. They realize up and down transmission functions. They receive different types of commands sent from main control units. In conjunction with that, they transmit down to subsystems inside the various assembly cases. At

the same time, they also automatically query at fixed intervals the operating statuses of different assembly housings. In conjunction with that, transmissions are made as necessary to main control units in order to realize automatic monitoring and control with regard to various assembly casings. /22

The priority ranking associated with the three levels of monitoring and control operations is that Level 1 is highest, Level 2 is next, and Level 3 is lowest. It is also sometimes said that the key control operations carried out on the panels of various assembly housings are capable of shielding from remote control operation commands that are sent from subsystem monitoring and control processors or the main control stations of the entire system. By the same reasoning, operations on subsystem monitoring and control processors are also capable of screening commands sent from main control units of the entire system. However, in order to facilitate unified control and management of the operations of different subsystems, subsystems are normally always operating in remote control mode. That is, commands sent from main control units are not screened. This article primarily discusses the role of telemetry subsystem monitoring and control processors in the telemetry and control system as a whole as well as the realization of telemetry subsystem monitoring and control automation.




Fig.1 Three Levels of Telemetry and Control System (1) Level 3 (2) Level 2 (3) Level 1 (4) Main Control Unit (5) Telemetry and Monitoring Device (6) Remote Control (7) Angular Measurement (8) Range Measurement (9) Centralizer (10) Receiver (11) Transmitter (12) Frequency Synthesizer (13) Digital Wave Filter (14) Main Synchronizer (15) Shunt Demodulator (16) Analog Signal Source (17) FSK Demodulation (18) Data Port

With regard to telemetry subsystems, the content associated with monitoring and control is mainly the two items set out below.

(1) Selection and Control of System and Equipment Operating Parameters. Principal operating parameters include the several types that follow--secondary carrier frequencies, code speed, code form, character length, frame length, frame synchronous code group length, input mode, and so on. Controls set these basic parameters, making telemetry systems operate in stable parameter configurations.

(2) Automatic Checks of Equipment Parameters and Configurations. During operational processes, automatic checks are carried out with regard to equipment parameters and configurations to be able to discover abnormalities in a timely manner and provide solutions in a timely way. For example, a certain assembly shows the appearance of malfunction. After automatic checks, the point of malfunction will immediately be displayed, letting operating personnel discover the malfunction in a timely and accurate manner and eliminate the malfunction in a timely way.

In sections below, introduction is made of the realization of software and hardware associated with communication between monitoring and control processors of telemetry subsystems as well as between other assemblies inside telemetry subsystems in order to realize automation of monitoring and control.

### 3 HARDWARE REALIZATION

#### 3.1 Telemetry Subsystem Monitoring and Control Processors and Main Control Units

(1) Agreements on Physics Levels. Physics levels are the lowest levels associated with communications agreements. Agreements on physics levels refer to agreements associated with connection electric levels and connection devices. Generally, there are the three types below.

The first type is EIA RS-232C. This is a type of serial port standard commonly used between computers. The utilization limits associated with this type of port are that maximum communication distances are not greater than 15m and baud rates are not greater than 19.2kbps.

The second type is EIA RS-422A. This is also a type of commonly used port standard. This type of port opts for the use of difference circuitry transmission. Limiting utilization parameters are that transmission distances not be greater than 120m and that baud rates not be larger than 1Mbps. The biggest advantages associated with this type of port are that it can be used in multiple point port methods and that it is suitable for use in communications between multiple processors.

The third type is 20mA current loop serial ports. The biggest advantages associated with this type of port are that low resistance transmission lines are not sensitive to electrical noise and that the realizing of photoelectric isolation is easy. However, each time data is transmitted, it is necessary to use a

currentless initial position to act as the first position of each group. When receiving terminals check initial positions, they then begin to receive a data group.

/23

Among the three types of commonly used port standards described above--on the basis of utilization requirements--we opt for the use of the second type of port standard, which is simple, easy to use, and capable of carrying out multiple processor communications. Due to serial porting of single chip devices in monitoring and control processors used in internal communications associated with telemetry subsystems, therefore, use is made of 8251A in order to expand serial porting in this regard so as to realize communication between telemetry subsystems and main control units. As far as port chips are concerned, MC3486 and MC3487 were selected for use. Their connection situation is shown in Fig.2. In order not to influence data transmission on communication trunk lines, there is a requirement that telemetry monitoring and control devices--when not transmitting data--should be in states of high resistance as associated with their transmission terminals sending to communication trunk lines. That is, telemetry monitoring and control devices let trunk lines out in order to facilitate not interfering with communications between main control units and monitoring and control devices associated with other subsystems. Here, use is made of 8251A output line DTR in order to control MC3487 outputs to make it possible for terminals to realize this function. With regard to 8251A single chip device control--when not transmitting data--the DTR terminal output is made a high electric level. In this way, MC3487 output terminals are high resistance states. After telemetry monitoring and control devices receive system main control unit commands, single chip device 8251A control makes the DTR outputs low electric levels, thereby causing MC3487 output terminals to be open states.




Fig.2 Line and Block Chart of the Realization of Hardware Circuitry Associated with Communication Between Main Control Units and Telemetry Monitoring and Control Devices (1) Single Chip Device (2) Data Line (3) Address Line (4) Control Line (5) Communication Port Chip (6) Going to Main Control Unit (7) Coming from Main Control Unit

(2) Key Circuit Level Agreements. This part of agreements refers to data group and data frame agreements.

In monitoring and control systems, communications between microcomputers opt for the use of asynchronous methods. Character groups are specified as follows. Position one is the initial position. Seven positions are data bits. One position is an odd parity bit. And, one position is the halt position. For the convenience of test measurements and debugging, full frame verification opts for the use of comparatively advanced international verification methods, thereby making all communications character groups be displayable and printable ASCII code--that is, making all ASCII code values associated with communications character groups exist in the interval 20H-7EH.





Fig.3 Hardware Connection Diagram for Communications to Main From Single Chip Devices Within Telemetry Subsystems (1) Master Device (2) Monitoring and Control Device (3) Slave Device 1 (4) Assembly 1 (5) Slave Device 2 (6) Assembly 2 (7) Slave Device 14 (8) Assembly 14

The data frame format is as follows.



(1) Frame Start (2) Address (3) Command or Response (4) Information (5) Frame End (6) Verification Code

Each data frame includes the six format blocks described above. In order to obtain displayable and printable verification codes, option is made for the use of the formula below to calculate verification codes (FCB).

$$FCB = MOD[\Sigma(CHA-32), 95] + 32$$

In this, CHA includes all the character groups between frame start and frame end.

(3) Agreements on Network Level and Above. During communications, we have made no use of functions at network level and above. Therefore, this is omitted.

### 3.2 Communications Between Monitoring and Control Processors Within Telemetry Subsystems and Various Assembly Device Housings

Monitoring and control processors must carry out communications with 14 (dual sets of thermal spare systems) assemblies. This type of communication makes use of 8031 single chip devices and is completed by TXD and RXD serial port communications lines. The communication method is master slave type asynchronous communication. The baud rate is 9.6kpbs. During master slave single chip device communications, 8031's in monitoring and control devices are used as masters. The connection method is shown in Fig.3.

/24

## 4 SOFTWARE DESIGN

As far as monitoring and control processors within telemetry subsystems are concerned, they are connected up to telemetry and control system main control units and connected down to 14 telemetry assembly device casings. There is a need to realize several tens of status inquiries and parameter settings. It is also necessary to complete configurations associated with 14 assembly device housings, automatically search for and check on malfunctions, and report up. In conjunction with this, there is a need for real time display of points of malfunction. In order to complete these numerous and complicated tasks, shorten single chip device waiting times, and improve single chip device operating efficiencies, in software design, option is made for the use of design methods combining suspensions and inquiries. In this way, telemetry monitoring and control processors are made able to respond in a timely manner to various types of commands coming from system main control units and also able to make single chip devices process other commands in a timely way. In order to improve communications reliability and counter interference performance, software designs opt for the use of software filter design methods. With regard to actual methods of realization, they are introduced hereafter.

### 4.1 Software Associated with Main Control Units and Telemetry Monitoring and Control Processors

This portion of software is used in receiving information sent from main control units. In order to respond rapidly to commands sent from main control units--with respect to data reception--option is made for the use of suspension methods in order to accomplish it. Moreover, after completing reception--with regard to data processing--option is made for the use of query methods for realization. During main programs associated with monitoring and

control devices, determinations are made at fixed times of whether or not suspended indices are set in position. During service suspension procedures, after monitoring and control devices finish receiving a data frame, this index is then set in position. After main programs determine that the suspended index is already set in position, implementation of a "process suspension index program section" is then gone into. In this section of program, first of all, address groups are determined. After this, verification is made of determinations of this group. Finally, command groups are determined. Distribution is carried out on the basis of commands received. If it is a setting command, in that case, a reply is first given to main control units, showing that data frames have already been received in their entirety. After that, there is a turning to the implementation of communications programs associated with the carrying out of communications with different assembly device housings, carrying out setting commands with regard to various assembly device casings. If it is a query command, then, query results required by main control stations will be sent. Fig.4 is the service suspension program flow chart. Fig.5 is the flow chart for "process suspension index program phases".




Fig.4 Service Suspension Program Flow Chart (1) Service Suspension Program Input (2) Input to Storage for Processing (3) Odd Parity Correct of Not? (4) Is Data "Frame Header"? (5) Received Address Initialization (6) "Frame Header" Send and Receive Addresses (7) Is Data "Frame End"? (8) "Frame End" Index in Position? (9) Suspension Index Set (10) "Frame End" Index In Position (11) Leave Storage for Processing (12) Leave Service Suspension Program




Fig.5 Flow Chart for Processing Suspension Index Program Sections  
 (1) Process Suspension Index Program Section Input (2) Address Groups Match or Not? (3) Leave This Program Section. (4) Group Verification Correct or Not? (5) After Sending Transmission Refused Code to Main Control Unit, Leave This Section. (6) Command Group Within Specified Range or Not? (7) Transmit Reception Refused Code to Main Control Unit. (8) Give a Response to Main Control Unit. (9) Leave This Program Section. (10) Command Dissemination

#### 4.2 Communications Software Associated with Telemetry Monitoring and Control Processors and Various Assembly Device Casings

This portion of communications makes use of serial port 8031 single chip devices for realization. Option is made for the use of master slave response communications methods. 8031's inside monitoring and control processors are the master devices. The 8031's inside the other assemblies are the slave devices. Fig.6 is the flow chart associated with master device and slave device communications. When master devices need to carry out /25 communications with slave devices, they first of all send out the slave device address to implement contact. After receiving slave device address responses, that shows that contact was successful. At this time, the master device is then able to continue to transmit data commands to slave devices. If N iterations of contact are not successful, it clearly shows that this slave device is not turned on or has shown the appearance of communications malfunctions. At this time, master devices then automatically take the news of this slave device showing the appearance of malfunctions and report it up to main control units. Fig.7 is the flow chart for slave device and master device communications. Slave devices make use of interruption methods to receive data sent from master devices. After receiving addresses sent from master devices, comparisons are made with the address of the receiver in question. If they are consistent, then, the suspension is withdrawn. Data commands sent out later are no longer received. After slave devices finish receiving data commands, on the basis of the commands received, dissemination is carried out, implementing different functions. After implementation is complete, a response is given to the master device. During communications, in order to improve the reliability of transmissions as well as counter jamming characteristics--besides opting for the use of bit parity in character group transmissions--in data frame transmissions, option is made for verification codes. Use is also made of software filter methods--that is, option is made for the use of methods of taking 2 in order to improve transmission reliability and counter interference characteristics. Making use of these three types of methods, transmission reliability and counter jamming characteristics are effectively improved.




Fig.6 Master Device and Slave Device Communication Flow Chart  
 (1) Start (2) Set Contact Iteration Number 3 (3) Send Out Extension Device Addresses (4) Set Timing Periods (5) Slave Devices Respond or Not? (6) Timing Periods Met or Not? (7) Addresses Match or Not? (8) Contact Iteration Number Reduced to 1 (9) Data Commands Sent Out to Slave Devices (10) Slave Unit Response Received (11) Contact Iteration Number Is 0? (12) Correct or Not? (13) Notify Main Control Unit that This Extension Device Has Malfunctioned (14) Get Out (15) Do Processing on the Basis of Response Received (16) Get Out




Fig.7 Slave Device and Master Device Communication Flow Chart (1) Suspension Program Entry (2) Enter Storage and Processing (3) Received Address of the Device in Question or Not? (4) Prepare to Receive Data (5) Receive Data (6) Give Response to Master Device (7) Disseminate on the Basis of Commands Received (8) Exit Storage and Processing (9) Leave Service Suspension Program

## 5 CONCLUDING REMARKS

This article introduced the setting up of monitoring and control nets in telemetry and control systems. Specific discussions were made of the realization of software and hardware corresponding to monitoring and control processors within telemetry subsystems. This set of systems is already applied in several telemetry and control stations associated with national defense science and industry committees. Satisfactory results have been achieved through test measurements, contact regulation, and test flights. The primary drawback is that speeds during operation are not fast enough. In particular, in situations where objects that need to be controlled are comparatively numerous, improving operating speeds is very necessary. In order to solve this problem, option is made for the use of even higher speed processor chips as a solution method.

## REFERENCES

### 参考文献

[1] 李明芬等,“TW-215 测控系统 JK 与 YC 监控器接口控制文件”,机电部十所,1990.

[2] Andrew S. Tanenbaum, "Computer Networks", Prentice-Hall, 1981.